



*Design by Helena Chmelíková*


**PRECIOSA Candy Rose**

111 01 385; 8 mm



**PRECIOSA Chili™**

111 77 788; 9 x 17 mm



**PRECIOSA Rocailles**

331 19 001; 10/0; 80/



*Preciosa Ornela introduces beads and seed beads  
from the PRECIOSA Traditional Czech Beads™ brand.*

Preciosa-Ornela.com



DELICATE ACCESSORY MADE USING PRECIOSA CANDY ROSE

# Floral *spray*



**PRECIOSA**

# Floral spray

We present an accessory consisting of the new engraved PRECIOSA Candy Rose bead in combination with the popular PRECIOSA Chilli™ bead. We make the PRECIOSA Candy Rose bead in two sizes: 8 mm and 12 mm.

They are available in a number of variants and in one or two-color versions with highlighted engraving.

## Materials and tools:

PRECIOSA Candy Rose  
111 01 385; 12 mm;  
02010/96845 pink; 1x (CR12)



111 01 385; 8 mm;  
02010/96845 pink; 2x (CR8)



PRECIOSA Chilli™ (Ch)  
111 01 357; 4 x 11 mm;  
02010/15726 purple; 12x



PRECIOSA Rocailles  
331 19 001; 10/0;  
03693 pink; 6x (R10)



331 19 001; 8/0;  
07332 pink; 4x (R8)



PRECIOSA Pressed Beads (B)  
111 19 003; 4 mm;  
02010/14494 pink; 2x



- a 0,20 mm nylon line; a thin needle; scissors




- a small hair clip or broach clasp  
(3,6 - 4 cm long); fast drying glue  
for non-absorbent material



Difficulty: ●●●●●

## Procedure:

Step 1:  
String 1x Ch through the outer hole in the dimple, 1xs Ch through the outer hole on the ridge, 1x CR8 through the first hole, 3x R10, the second hole of the CR8, 1x Ch through the outer hole in the dimple and 1x Ch through the outer hole on the ridge. Thread the line through both holes in the first Ch.  
step 1 - 3



Step 2:  
String the first hole of the CR12.  
Ensure that the bead is oriented in the same way as the CR8. String 1x Ch and thread the line through both holes starting from the central hole in the dimple.  
String 1x Ch through the outer hole in the dimple.




Step 3:  
String 1x Ch through the outer hole on the ridge, 1x CR8 through the first hole, 3x R10, the second hole of the CR8 and

1x Ch through the outer hole in the dimple. Thread the line through the outer hole on the ridge of the already strung Ch above the CR12. Thread the line through both holes in the next Ch above the CR12. Thread the line through the second hole of the CR12. Thread the line through both holes in the adjacent Ch. Tie off both ends of the line. Pull them into the surrounding beads and cut them off.



Step 4:  
Thread the line around the circumference of the already strung beads. Thread the line through one hole of the CR12 and the central holes of the two Ch which are above one another and additionally string 1x R8 between them. String a new Ch through both holes starting with the outer hole in the dimple. Thread the line through one hole in the CR8. String 1x B. Grasp the line between two Ch above the CR12. Return to the B. Thread the line through the second hole of the CR8. String a new Ch through both holes starting with the central hole in the dimple. Thread the line through the central hole of the two Ch which are above one another and additionally string 1x R8 between them.

step 4 - 5



Step 5:  
Repeat Step 4 on the mirror-image side of the Spray. Tie of the line at the end. Pull it into the surrounding beads and cut it off.



Step 6:  
Prepare the glue according to the instructions. Apply it and then attach the Spray. Hold it in place and wait until the glue dries.

