




Design by Helena Chmelíková

PRECIOSA Engraved Pip

111 01 391; 9 x 14 mm



PRECIOSA Rocailles

311 19 001; 10/0; 8/0



PRECIOSA Rocailles

331 29 001; 10/0



*Preciosa Ornela introduces beads and seed beads
from the PRECIOSA Traditional Czech Beads™ brand.*

Preciosa-Ornela.com



DISTINCTIVE BRACELET MADE FROM PRECIOSA ENGRAVED PIP

Scales



PRECIOSA

Scales

We have prepared a new PRECIOSA Engraved Pip bead for you, the shape of which is based on the classic PRECIOSA Pip™ bead. You are sure to appreciate the distinctive embossed line that is reminiscent of the venation of leaves or the patterns on the scales of fish or lizards. Choose from the wide range of varied finishes.

Materials and tools:

PRECIOSA Engraved Pip (P)
111 01 391; 9 x 14 mm;
02010/65325; veiled green; 73x



PRECIOSA Rocailles
311 19 001; 10/0;
any opaque shade; 25x (R10)



311 19 001; 8/0;
any opaque shade; 30x (R8)



PRECIOSA Rocailles (R15)
331 29 001; 10/0;
57290; khaki; 16x



PRECIOSA Fire Polished Beads (FPB)
151 19 001; 12 mm;
50230; khaki; 1x



- caps (14 x 14 mm); a large carabiner;
a metal crimp bead (CB); 8 mm and 6 mm rings;
a thin 5 mm ring



- a regular 0.38 mm wire; a 0.20 mm nylon line;
a thin needle; scissors; snipping pliers; flat-nose
pliers (for handling the rings and the CB)



Difficulty: ●●●●●


Technique: stringing

Procedure:

Step 1:
String 3x P onto the line. Thread the line
through them one more time. Tighten it.
Tie two knots. Pull the ends into the two holes
and cut them off.




Step 2:
You need 24 cornets with three leaves.



Step 3:
Cut off 50 cm of wire. String 1x CB, 1x R8,
1x CB, 1x R8 and the cap through the dimpled
side. Continue by stringing 8x R15.
Return the wire to the cap. This will create
a loop of R15. Also thread it through the R8 and
the CB.





Step 4:
Grip the CB close to the dimple using
the flat-nosed pliers. Move it in as deeply into
the dimple as possible and crimp it. Do the same
with the second CB.



Step 5:
String the cornet through the pointed end.
Add 1x R10 and 1x R8 to it. Repeat this a total
of 24x. Start stringing on the short and long ends
of the wire. Then only work on the long end.



Step 6:
Instead of the last R8, string 2x CB, 1x FPB,
3 more R8, a cap from the dimple and 8x R15.
Return the wire to the cap. This will create
a loop. Also thread it through the R8, FPB, CB,
several cornets and the R10 and R8 between
them.



Step 7:
Cut off the wire. Crimp 2x CB. Hold the end
of the wire. Cut off the protruding section.

Step 8:
Make an adjusting chain from the 8 mm rings.
String two rings onto the loop of R15 and close
them. Connect two new rings to these two.
Repeat this 6 more times (a total of 8x).
Thread the thin 5 mm ring through the hole
in the P and connect it to the outer rings.



Step 9:
Attach the carabiner to the second loop of R15
using a 6 mm ring.